

AIR-INTAKE SYSTEM, THROTTLE VALVE & CARBURETTOR CLEANER

Dissolves dirt accumulation, cleaning and maintaining the entire air-intake system.

CHARACTERISTICS

- maintains and cleans the entire air-intake system
- lowers fuel consumption
- quick and effective
- compatible with all sorts of material
- 360° valve

TECHNICAL DATA

processing temperature	warm engine
shelf life	36 months; store in a cool and dry place

INSTRUCTIONS FOR USE

Shake well before use. If necessary, insert the spray probe of the PETEC air-intake system cleaner through the air filter and spray contaminated parts. Start the engine and the cleaner with the engine running for approx. 60 seconds in spray intervals. Then cut off the engine and leave to take effect for 10 – 15 minutes. Repeat the procedure several times in case of stubborn dirt. Only use while engine is running!

Observe the safety and technical datasheet! (Download PETEC data sheets from www.petec.de)

CONTAINER SIZE



Item-No. 72450

500 ml spray