

MIXING TUBE

Features

For 2C double syringes and double cartridges

for:

2C PU adhesive (item no. 98325 / 98350)

Liquid plastic (item no. 98355)

Power BiBond (item no. 98625 / 98550)

POXY (item no. 98425 / 98050)

Liquid metal (item no. 97355)

Areas of application



TechnicalData

Shelf life	Months
------------	--------

Usage Instructions

Turn the cap of the double cartridge 90° to the left and remove it. Then attach the mixing tube and turn 90° to the right to lock it. Using the applicator gun (item no. 98502), squeeze out the adhesive in the double syringe (containing 24 ml) through the double piston or double cartridge (containing 50 ml). The adhesive can be applied directly through the mixing tube to the bonding surface. Before starting with the bonding, please squeeze out a small amount (approx. 3 cm) of the mixed adhesive and discard it. In this way the correct mixing ratio is ensured and the product is ready for use. The mixing tubes are not suitable for use with our "liquid metal" (item no. 97425), because the adhesive is too thick.

Package Sizes

	
Item no.: 98510	Item no.: 98512
for 24 ml/50 ml	for 24 ml/50 ml