

## MIXING TUBES

### Features

For 2C double syringes and double cartridges

for:

2C PU adhesive (item no. 98325 / 98350)

Liquid plastic (item no. 98355)

Power BiBond (item no. 98625 / 98550)

POXY (item no. 98425 / 98050)

Liquid metal (item no. 97355)

### Areas of application


### TechnicalData

Shelf life	Months
------------	--------

### Usage Instructions

Turn the cap of the double cartridge 90° to the left and remove it. Then attach the mixing tube and turn 90° to the right to lock it. Using the applicator gun (item no. 98502), squeeze out the adhesive in the double syringe (containing 24 ml) through the double piston or double cartridge (containing 50 ml). The adhesive can be applied directly through the mixing tube to the bonding surface. Before starting with the bonding, please squeeze out a small amount (approx. 3 cm) of the mixed adhesive and discard it. In this way the correct mixing ratio is ensured and the product is ready for use.

### Package Sizes

		
<p><b>Item no.:</b></p>	<p><b>Item no.: 98603</b></p>	<p><b>Item no.: 98513</b></p>
<p>für 24 ml/50 ml</p>	<p>3-pack 24 ml/50 ml</p>	<p>1 Stück</p>

Our technical application advice, whether verbal, in writing, or based on tests, is provided to the best of our current knowledge. However, it does not release you from the obligation to independently verify the suitability of the products we supply for the intended processes and purposes. The application, use, and processing of the products are beyond our control and therefore fall solely within your area of responsibility.